

Tennis net installation guide

Internal winding post net installation

TNPCSAT & TNPSSAT

1. Unpack posts and slide into ground sleeves making sure that the net tie points are positioned to the inside of the court, the winder posts can be positioned on either side of the court.
2. Hook the loop end of the net cable onto the hook on the tie posts making sure that the cable is positioned in the groove on the cap at the top of the post.
3. Pull the cable tight and position it over the winder post pulley, pull firmly down over the outside of the winder post, making sure that when the cable is tight, there is no more than 300mm of cable extending past the handle point. If there is, cut off the excess cable. Note by not doing this the net warranty will be voided.
4. Turn the handle in the direction of the arrow until you locate a grub screw inside the mechanism of the winder drum, when located loosen the grub screw with a flathead screwdriver.
5. Remove the cap from the winder of the post.
6. Thread the cable over and down through the top of the cap and over the pulley located on the winder post and feed it out through the face plate where the grub screw is located. It is easier to have two people to do this.
7. Twist the cable in a "U" shape and push it as far as it will go into the hole located below the grub screw in the winder drum, while holding it firmly in place, lock up the grub screw. Not too tight or
8. You will strip the thread.
9. Let go of the cable making sure it is in the correct position over the pulleys on both posts, hold the cable tight while winding up the handle feeding the cable evenly over the winding drum as you tension the net to the correct height (i.e. 915mm from the playing surface to the top of the net at the centre of the court.)
10. Tie off the net to the crinkle system on the post, on one side only starting at the top and working your way down the post keeping the net as close as possible to the post then go to the other post and stretch the net as close as possible to the tie off points, this may require two people to do this. Start at the top and work your way down again.
11. It may be necessary to readjust the net evenly on each side until the net stretches to its full capacity.
12. The net might need to be readjusted in a couple of weeks after it has stretched fully.

External winding post net installation

TNPSDW36A & TNPB

1. Hook the net onto the hook side of the set of posts.
2. Loosen the rope grip before winding.
3. Ensure the winder's side is wound down to the end of the rod. Do not wind the handle off the end of the rod.
4. Hook the net to the top winder side post
5. Wind the handle until the net is tensioned.
6. Tighten wire rope grip.

Grandslam Sports Equipment